Installation Guide

English

SPARC® Enterprise T5140 / T5240 Servers

We make sure

FUJITSU COMPUTERS SIEMENS

FUJITSU COMPUTERS SIEMENS

SPARC® Enterprise T5140 and T5240 Servers Installation Guide

Order No. U41767-J-Z816-1-76
Part No. 875-4310-10
February 2008, Revision A

Copyright 2008 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

FUJITSU LIMITED provided technical input and review on portions of this material.

Sun Microsystems, Inc. and Fujitsu Limited each own or control intellectual property rights relating to products and technology described in this document, and such products, technology and this document are protected by copyright laws, patents and other intellectual property laws and international treaties. The intellectual property rights of Sun Microsystems, Inc. and Fujitsu Limited in such products, technology and this document include, without limitation, one or more of the United States patents listed at http://www.sun.com/patents and one or more additional patents or patent applications in the United States or other countries.

This document and the product and technology to which it pertains are distributed under licenses restricting their use, copying, distribution, and decompilation. No part of such product or technology, or of this document, may be reproduced in any form by any means without prior written authorization of Fujitsu Limited and Sun Microsystems, Inc., and their applicable licensors, if any. The furnishing of this document to you does not give you any rights or licenses, express or implied, with respect to the product or technology to which it pertains, and this document does not contain or represent any commitment of any kind on the part of Fujitsu Limited or Sun Microsystems, Inc., or any affiliate of either of them.

This document and the product and technology described in this document may incorporate third-party intellectual property copyrighted by and/or licensed from suppliers to Fujitsu Limited and/or Sun Microsystems, Inc., including software and font technology.

Per the terms of the GPL or LGPL, a copy of the source code governed by the GPL or LGPL, as applicable, is available upon request by the End User. Please contact Fujitsu Limited or Sun Microsystems, Inc.

This distribution may include materials developed by third parties.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and in other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, Java, Netra, Solaris, Sun StorEdge, docs.sun.com, OpenBoot, SunVTS, Sun Fire, SunSolve, CoolThreads, J2EE, and Sun are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

Fujitsu and the Fujitsu logo are registered trademarks of Fujitsu Limited.

All SPARC trademarks are used under license and are registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon architecture developed by Sun Microsystems, Inc.

SPARC64 is a trademark of SPARC International, Inc., used under license by Fujitsu Microelectronics, Inc. and Fujitsu Limited.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

United States Government Rights - Commercial use. U.S. Government users are subject to the standard government user license agreements of Sun Microsystems, Inc. and Fujitsu Limited and the applicable provisions of the FAR and its supplements.

Disclaimer: The only warranties granted by Fujitsu Limited, Sun Microsystems, Inc. or any affiliate of either of them in connection with this document or any product or technology described herein are those expressly set forth in the license agreement pursuant to which the product or technology is provided. EXCEPT AS EXPRESSLY SET FORTH IN SUCH AGREEMENT, FUJITSU LIMITED, SUN MICROSYSTEMS, INC. AND THEIR AFFILIATES MAKE NO REPRESENTATIONS OR WARRANTIES OF ANY KIND (EXPRESS OR IMPLIED) REGARDING SUCH PRODUCT OR TECHNOLOGY OR THIS DOCUMENT, WHICH ARE ALL PROVIDED AS IS, AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID. Unless otherwise expressly set forth in such agreement, to the extent allowed by applicable law, in no event shall Fujitsu Limited, Sun Microsystems, Inc. or any of their affiliates have any liability to any third party under any legal theory for any loss of revenues or profits, loss of use or data, or business interruptions, or for any indirect, special, incidental or consequential damages, even if advised of the possibility of such damages.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 2008 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, Etats-Unis. Tous droits réservés.

Entrée et revue tecnical fournies par FUJITSU LIMITED sur des parties de ce matériel.

Sun Microsystems, Inc. et Fujitsu Limited détiennent et contrôlent toutes deux des droits de propriété intellectuelle relatifs aux produits et technologies décrits dans ce document. De même, ces produits, technologies et ce document sont protégés par des lois sur le copyright, des brevets, d'autres lois sur la propriété intellectuelle et des traités internationaux. Les droits de propriété intellectuelle de Sun Microsystems, Inc. et Fujitsu Limited concernant ces produits, ces technologies et ce document comprennent, sans que cette liste soit exhaustive, un ou plusieurs des brevets déposés aux États-Unis et indiqués à l'adresse http://www.sun.com/patents de même qu'un ou plusieurs brevets ou applications brevetées supplémentaires aux États-Unis et dans d'autres pays.

Ce document, le produit et les technologies afférents sont exclusivement distribués avec des licences qui en restreignent l'utilisation, la copie, la distribution et la décompilation. Aucune partie de ce produit, de ces technologies ou de ce document ne peut être reproduite sous quelque forme que ce soit, par quelque moyen que ce soit, sans l'autorisation écrite préalable de Fujitsu Limited et de Sun Microsystems, Inc., et de leurs éventuels bailleurs de licence. Ce document, bien qu'il vous ait été fourni, ne vous confère aucun droit et aucune licence, expresses ou tacites, concernant le produit ou la technologie auxquels il se rapporte. Par ailleurs, il ne contient ni ne représente aucun engagement, de quelque type que ce soit, de la part de Fujitsu Limited ou de Sun Microsystems, Inc., ou des sociétés affiliées.

Ce document, et le produit et les technologies qu'il décrit, peuvent inclure des droits de propriété intellectuelle de parties tierces protégés par copyright et/ou cédés sous licence par des fournisseurs à Fujitsu Limited et/ou Sun Microsystems, Inc., y compris des logiciels et des technologies relatives aux polices de caractères.

Par limites du GPL ou du LGPL, une copie du code source régi par le GPL ou LGPL, comme applicable, est sur demande vers la fin utilsateur disponible; veuillez contacter Fujitsu Limted ou Sun Microsystems, Inc.

Cette distribution peut comprendre des composants développés par des tierces parties.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, Java, Netra, Solaris, Sun StorEdge, docs.sun.com, OpenBoot, SunVTS, Sun Fire, SunSolve, CoolThreads, J2EE, et Sun sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays.

Fujitsu et le logo Fujitsu sont des marques déposées de Fujitsu Limited.

Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

SPARC64 est une marques déposée de SPARC International, Inc., utilisée sous le permis par Fujitsu Microelectronics, Inc. et Fujitsu Limited.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une license non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui, en outre, se conforment aux licences écrites de Sun.

Droits du gouvernement américain - logiciel commercial. Les utilisateurs du gouvernement américain sont soumis aux contrats de licence standard de Sun Microsystems, Inc. et de Fujitsu Limited ainsi qu'aux clauses applicables stipulées dans le FAR et ses suppléments.

Avis de non-responsabilité: les seules garanties octroyées par Fujitsu Limited, Sun Microsystems, Inc. ou toute société affiliée de l'une ou l'autre entité en rapport avec ce document ou tout produit ou toute technologie décrit(e) dans les présentes correspondent aux garanties expressément stipulées dans le contrat de licence régissant le produit ou la technologie fourni(e). SAUF MENTION CONTRAIRE EXPRESSÉMENT STIPULÉE DANS CE CONTRAT, FUJITSU LIMITED, SUN MICROSYSTEMS, INC. ET LES SOCIÉTÉS AFFILIÉES REJETTENT TOUTE REPRÉSENTATION OU TOUTE GARANTIE, QUELLE QU'EN SOIT LA NATURE (EXPRESSE OU IMPLICITE) CONCERNANT CE PRODUIT, CETTE TECHNOLOGIE OU CE DOCUMENT, LESQUELS SONT FOURNIS EN L'ÉTAT. EN OUTRE, TOUTES LES CONDITIONS, REPRÉSENTATIONS ET GARANTIES EXPRESSES OU TACITES, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE À LA QUALITÉ MARCHANDE, À L'APTITUDE À UNE UTILISATION PARTICULIÈRE OU À L'ABSENCE DE CONTREFAÇON, SONT EXCLUES, DANS LA MESURE AUTORISÉE PAR LA LOI APPLICABLE. Sauf mention contraire expressément stipulée dans ce contrat, dans la mesure autorisée par la loi applicable, en aucun cas Fujitsu Limited, Sun Microsystems, Inc. ou l'une de leurs filiales ne sauraient être tenues responsables envers une quelconque partie tierce, sous quelque théorie juridique que ce soit, de tout manque à gagner ou de perte de profit, de problèmes d'utilisation ou de perte de données, ou d'interruptions d'activités, ou de tout dommage indirect, spécial, secondaire ou consécutif, même si ces entités ont été préalablement informées d'une telle éventualité.

LA DOCUMENTATION EST FOURNIE "EN L'ETAT" ET TOUTES AUTRES CONDITIONS, DECLARATIONS ET GARANTIES EXPRESSES OU TACITES SONT FORMELLEMENT EXCLUES, DANS LA MESURE AUTORISEE PAR LA LOI APPLICABLE, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE A LA QUALITE MARCHANDE, A L'APTITUDE A UNE UTILISATION PARTICULIERE OU A L'ABSENCE DE CONTREFACON.

Contents

Preface xiii

1. Preparing for Installation 1

Tools and Equipment Needed 3

Optional Component Installation 3

ESD Precautions 3

Installation Overview 4

Cabling Notes for Both Servers 6

Port, Connector, and LED Locations for Both Servers 7

Slide Rail Assembly Notes for Both Servers 10

Cable Management Notes for Both Servers 13

Safety Precautions 14

2. Installing the SPARC Enterprise T5140 and T5240 Servers 15

Installing the Servers in a Rack 15

- To Install the Slide Rail Assemblies 16
- To Insert and Lock the Server in the Rack 22

Installing the Cable Management Arm for Both Servers 24

- To Install the Cable Management Arm 24
- To Verify the Operation of the Slide Rails and the CMA 29

Connecting the Server Cables for Both Servers 31

- To Connect the Service Processor Serial Management Port 31
- To Connect the Service Processor Network Management Port 32
- To Connect the Ethernet Network Cables 33
- To Connect the AC Power Cable to the Server 34

Managing Cables With the CMA 34

- Securing the Server Cables in the CMA 35

Dismounting the Servers 35

3. Powering On the System 37

Powering On the System for the First Time 37

ILOM System Console 37

ILOM Service Processor 38

- To Power On the System for the First Time 38

Enabling the Service Processor Network Management Port 44

Logging Into the Service Processor 45

- To Log Into the Service Processor Using the Serial Management Port 45
- To Configure the Service Processor Network Management Port 47
- To Log Into the Service Processor Using the Network Management Port 50

Using the Service Processor for Common Operations 50

- To Power On the System 51
- To Connect to the System Console 53
- To Perform a Normal System Initialization 53

Devices in the OpenBoot Device Tree 55

Booting the Solaris Operating System 56

- To Boot the Solaris Operating System 56
- To Avoid Booting the Solaris Operating System at Start Up 57
- To Reset the System 57

▼ To Power Cycle the System 57

Verifying System Functionality 59

A. Updating the Firmware 61

The `flashupdate` command 61

Updating the Firmware 61

▼ To Update the Firmware 62

B. Selecting a Boot Device 65

Selecting a Boot Device 65

▼ To Select a Boot Device 66

C. Installing the Servers With the Express Rail Rackmounting Kit 67

Slide Rail Assembly Notes for the Express Rail Rackmounting Kit 68

Installing the Servers in a Rack With Express Rails 71

▼ To Install the Slide Rail Assemblies 71

▼ To Insert and Lock the Server in the Rack 76

Installing the Cable Management Arm 79

Connecting the Server Cables 79

Managing Cables With the CMA 79

Dismounting the Server 79

Index 81

Figures

FIGURE 1-1 SPARC Enterprise T5140 Server 2

FIGURE 1-2 SPARC Enterprise T5240 Server 2

FIGURE 1-3 Rear Panel Cable Connectors and LEDs on the SPARC Enterprise T5140 Server 8

FIGURE 1-4 Front Panel USB Ports on the SPARC Enterprise T5140 Server 8

FIGURE 1-5 Rear Panel Cable Connectors and LEDs on the SPARC Enterprise T5240 Server 9

FIGURE 1-6 Front Panel USB Ports on the SPARC Enterprise T5240 Server 10

FIGURE 1-7 Sections of the Slide Rail Assembly on the SPARC Enterprise T5240 Server 11

FIGURE 1-8 Locating the Locks on the Slide Rail Assembly for the SPARC Enterprise T5240 Server 12

FIGURE 1-9 Cable Management Arm for Both Servers 13

FIGURE 2-1 Unlocking the Slide Rail Assembly (Either Server) 16

FIGURE 2-2 Location of the Mounting Bracket Release Button (Either Server) 17

FIGURE 2-3 Unlocking the Slide Rail Middle Section (Either Server) 18

FIGURE 2-4 Attaching a Mounting Bracket to the Chassis (Either Server) 19

FIGURE 2-5 Mounting a Slide Rail (Either Server) 20

FIGURE 2-6 Using the Slide Rail Spacing Tool to Adjust the Distance Between the Slide Rails (Either Server) 21

FIGURE 2-7 Mounting the Chassis on the Slide Rails (Either Server) 23

FIGURE 2-8 Inserting the CMA Rail Extension Into the Rear of the Left Slide Rail (Either Server) 25

FIGURE 2-9 Mounting the Inner CMA Connector (Either Server) 26

FIGURE 2-10 Attaching the Outer CMA Connector (Either Server) 27

FIGURE 2-11 Mounting the Left Side of the Slide Rail (Either Server) 28

FIGURE 2-12 Unlocking the Slide Rail Assembly (Either Server) 29
FIGURE 2-13 Rail Mounting Bracket Release Button (Either Server) 30
FIGURE 2-14 Service Processor Serial Management Port – Rear Panel 32
FIGURE 2-15 Service Processor Network Management Port – Rear Panel 33
FIGURE 2-16 Service Processor Ethernet Network Ports – Rear Panel 34
FIGURE 2-17 Securing the Server Cables With the CMA and Velcro Straps (Either Server) 35
FIGURE 3-1 Server Connections 40
FIGURE C-1 Sections of the Express Rail Slide Rail Assembly 68
FIGURE C-2 Locating the Locks on the Slide Rail Assembly for the SPARC Enterprise T5240 Server 70
FIGURE C-3 Unlocking the Express Rail Slide Rail Assembly 72
FIGURE C-4 Express Rail Mounting Bracket Release Button 73
FIGURE C-5 Attaching an Express Rail Mounting Bracket to the Chassis 74
FIGURE C-6 Express Rail Slide Rails Orientation for Installation 75
FIGURE C-7 Attaching Express Slide Rails to the Rack 76
FIGURE C-8 Inserting Express Rail Mounting Brackets Into the Slide Rails 77
FIGURE C-9 Sliding the Express Rail Release Tab and Securing the Server in the Rack 78

Tables

TABLE 1-1 Ethernet Connection Transfer Rates 7

TABLE 3-1 Disk Slot Numbers, Logical Device Names, and Physical Device Names 55

TABLE 3-2 Device Identifiers and Devices 55

Preface

This manual provides instructions, background information, and reference material to help you install SPARC® Enterprise T5140 and T5240 servers.

The installation instructions in this document assume that a system administrator is experienced with the Solaris™ Operating System (Solaris OS).

Note – All internal components except hard drives must be installed by qualified service technicians only.

FOR SAFE OPERATION

This manual contains important information regarding the use and handling of this product. Read this manual thoroughly. Pay special attention to the section "Notes on Safety" on page xix. Use the product according to the instructions and information available in this manual. Keep this manual handy for further reference.
Fujitsu Siemens Computers makes every effort to prevent users and bystanders from being injured or from suffering damage to their property. Use the product according to this manual.

Structure and Contents of This Manual

This manual is organized as described below:

Chapter 1 provides an installation overview for the servers.

Chapter 2 provides instructions for installing the servers into a rack.

Chapter 3 provides instructions for configuring and powering on the servers, and for installing additional software.

Appendix A provides instructions for updating the service processor firmware and the system firmware.

Appendix B provides instructions for selecting a boot device.

Appendix C provides instructions for installing the servers into a rack with the express rail rackmounting kit.

Related Documentation

The latest versions of all the SPARC Enterprise Series manuals are available at the following Web sites:

http://manuals.fujitsu-siemens.com/

Title	Description	Order No.
SPARC Enterprise T5140 and T5240 Servers Product Notes	Information about the latest product updates and issues	U41765-J-Z816-x-76
SPARC Enterprise T5140 and T5240 Servers Overview Guide	Product features	U41764-J-Z816-x-76
SPARC Enterprise T5140 and T5240 Servers Site Planning Guide	Server specifications for site planning	U41766-J-Z816-x-76
SPARC Enterprise T5140 and T5240 Servers Service Manual	How to run diagnostics to troubleshoot the server, and how to remove and replace parts in the server	U41768-J-Z816-x-76
SPARC Enterprise T5140 and T5240 Servers Administration Guide	How to perform administrative tasks that are specific to the servers	U41769-J-Z816-x-76
Integrated Lights Out Manager 2.0 User's Guide	Information that is common to all platforms managed by ILOM	U41754-J-Z816-x-76
Integrated Lights Out Manager 2.0 Supplement for SPARC Enterprise T5140 and T5240 Servers	How to use the Integrated Lights Out Manager (ILOM) software on the servers	U41771-J-Z816-x-76
SPARC Enterprise T5140 and T5240 Servers Safety and Compliance Guide	Safety and compliance information that is specific to the servers	U41772-J-Z816-x-76

Note – "x" in the order number is the version number of the manual.

Note – Product Notes is available on the website only. Please check for the recent update on your product.

Using UNIX Commands

This document might not contain information about basic UNIX® commands and procedures such as shutting down the system, booting the system, and configuring devices. Refer to the following for this information:

- Software documentation that you received with your system
- Solaris™ Operating System documentation, which is at:

  http://docs.sun.com

Text Conventions

This manual uses the following fonts and symbols to express specific types of information.

Typeface*	Meaning	Example
AaBbCc123	The names of commands, files and directories; on-screen computer output	Edit your.login file. Use ls -a to list all files. % You have mail.
AaBbCc123	What you type, when contrasted with on-screen computer output	% **su** Password:
AaBbCc123	Book titles, new words or terms, words to be emphasized. Replace command-line variables with real names or values.	Read Chapter 6 in the *User's Guide*. These are called *class* options. You *must* be superuser to do this. To delete a file, type rm *filename*.

* The settings on your browser might differ from these settings.

Prompt Notations

The following prompt notations are used in this manual.

Shell	Prompt
C shell	*machine-name*%
C shell superuser	*machine-name*#
Bourne shell and Korn shell	$
Bourne shell and Korn shell superuser	#
ILOM service processor	->
ALOM compatibility shell	sc>
OpenBoot™ PROM firmware	ok

Conventions for Alert Messages

This manual uses the following conventions to show alert messages, which are intended to prevent injury to the user or bystanders as well as property damage, and important messages that are useful to the user.

Warning – This indicates a hazardous situation that could result in death or serious personal injury (potential hazard) if the user does not perform the procedure correctly.

Caution – This indicates a hazardous situation that could result in minor or moderate personal injury if the user does not perform the procedure correctly. This signal also indicates that damage to the product or other property may occur if the user does not perform the procedure correctly.

Caution – This indicates that surfaces are hot and might cause personal injury if touched. Avoid contact.

Caution – This indicates that hazardous voltages are present. To reduce the risk of electric shock and danger to personal health, follow the instructions.

Tip – This indicates information that could help the user to use the product more effectively.

Alert messages in the text

An alert message in the text consists of a signal indicating an alert level followed by an alert statement. Alert messages are indented to distinguish them from regular text. Also, a space of one line precedes and follows an alert statement.

Caution – The following tasks regarding this product and the optional products provided from Fujitsu Siemens Computers should only be performed by a certified service engineer. Users must not perform these tasks. Incorrect operation of these tasks may cause malfunction.

- Unpacking optional adapters and such packages delivered to the users

Also, important alert messages are shown in "Important Alert Messages" on page xix.

Notes on Safety

Important Alert Messages

This manual provides the following important alert signals:

Caution – This indicates a hazardous situation could result in minor or moderate personal injury if the user does not perform the procedure correctly. This signal also indicates that damage to the product or other property may occur if the user does not perform the procedure correctly.

Task	Warning
Installation	**Damage** Deploy the antitilt feature on the rack before beginning an installation. The SPARC Enterprise T5240 server weighs approximately 46 lb (20.7 kg). Two people are required to lift and mount the system into a rack enclosure when using the procedures in this book. When completing a two-person procedure, always communicate your intentions clearly before, during, and after each step to minimize confusion. The weight of the server on extended slide rails can be enough to overturn an equipment rack.

Caution – This indicates that hazardous voltages are present. To reduce the risk of electric shock and danger to personal health, follow the instructions.

Task	Warning
Installation	**Electric shock** There is a potential for electric shock if the server and related equipment are not properly grounded.

Product Handling

Maintenance

Warning – Certain tasks in this manual should only be performed by a certified service engineer. User must not perform these tasks. Incorrect operation of these tasks may cause electric shock, injury, or fire.

- Installation and reinstallation of all components, and initial settings
- Removal of front, rear, or side covers
- Mounting/de-mounting of optional internal devices
- Plugging or unplugging of external interface cards
- Maintenance and inspections (repairing, and regular diagnosis and maintenance)

Caution – The following tasks regarding this product and the optional products provided from Fujitsu Siemens Computers should only be performed by a certified service engineer. Users must not perform these tasks. Incorrect operation of these tasks may cause malfunction.

- Unpacking optional adapters and such packages delivered to the users
- Plugging or unplugging of external interface cards

Remodeling/Rebuilding

Caution – Do not make mechanical or electrical modifications to the equipment. Using this product after modifying or reproducing by overhaul may cause unexpected injury or damage to the property of the user or bystanders.

Alert Label

The following is a label attached to this product:

- Never peel off the label.
- The following label provides information to the users of this product.


SPARC Enterprise T5240
System Overview and Service Information
ATTENTION
System WILL SHUT DOWN when top cover is removed.
Power down system before removing top cover.

Example: SPARC Enterprise T5240 Server

Fujitsu Siemens Computers Welcomes Your Comments

We would appreciate your comments and suggestions to improve this document. You can submit your comments by using "Reader's Comment Form."

▪ Reader's Comment Form

We would appreciate your comments and suggestions for improving this publication.

Date:_____ Publication No.:
Your Name:_____ Publication Name:
Company: _____
Address: _____
City/State/Zip:_____
Phone/Email address: _____

Your Comments:

Page	Line	Comments
Reply requested: o Yes o No		

Please evaluate the overall quality of this manual by checking (✓)the appropriate boxes

	Good	Fair	Poor		Good	Fair	Poor		Good	Fair	Poor
Organization:	o	o	o	Use of examples:	o	o	o	Legibility:	o	o	o
Accuracy:	o	o	o	Index coverage:	o	o	o	Binding:	o	o	o
Clarity:	o	o	o	Cross				Figures and tables:	o	o	o
Overall rating of				referencing:	o	o	o	General appearance:	o	o	o
this publication:	o	o	o								

Technical level: o Too detailed o Appropriate o Not enough detail

All comments and suggestions become the property of Fujitsu Limited.

For Users in U.S.A., Canada, and Mexico

Fold and fasten as shown on back
No postage necessary if mailed in U.S.A.

Fujitsu Computer Systems
Attention: Engineering Ops M/S 249
1250 East Arques Avenue
P.O. Box 3470
Sunnyvale, CA 94088-3470
FAX: (408) 746-6813

For Users in Other Countries

Fax this form to the number below or send this form to the address below.

Fujitsu Learning Media Limited
FAX: 81-3-3730-3702
37-10 Nishi-Kamata 7-chome
Oota-Ku
Tokyo 144-0051
JAPAN

FUJITSU LIMITED

FOLD AND TAPE

NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO 741 SUNNYVALE CA

POSTAGE WILL BE PAID BY ADDRESSEE

FUJITSU

FUJITSU COMPUTER SYSTEMS
ATTENTION ENGINEERING OPS M/S 249
1250 EAST ARQUES AVENUE
P O BOX 3470
SUNNYVALE CA 94088-3470

FOLD AND TAPE

CHAPTER 1

Preparing for Installation

This chapter provides background information about the installation procedures for both servers that are provided in Chapter 2.

This chapter contains these topics:

- "Tools and Equipment Needed" on page 3
- "Optional Component Installation" on page 3
- "ESD Precautions" on page 3
- "Installation Overview" on page 4
- "Cabling Notes for Both Servers" on page 6
- "Slide Rail Assembly Notes for Both Servers" on page 10
- "Cable Management Notes for Both Servers" on page 13
- "Safety Precautions" on page 14

The SPARC Enterprise T5140 server is a 1 rack unit (1U) server (FIGURE 1-1). The SPARC Enterprise T5240 server is a 2 rack unit (2U) server (FIGURE 1-2).

FIGURE 1-1 SPARC Enterprise T5140 Server

FIGURE 1-2 SPARC Enterprise T5240 Server



Tools and Equipment Needed

To install the system, you must have the following tools:

- No. 2 Phillips screwdriver
- ESD mat and grounding strap

In addition, you must provide a system console device, such as one of the following:

- ASCII terminal
- Workstation
- Terminal server
- Patch panel connected to a terminal server

Optional Component Installation

The standard components of the server are installed at the factory. However, if you ordered options such as additional memory or PCI cards, these will be shipped separately. If possible, install these components prior to installing the server in a rack.

If you ordered any options that are not factory-installed, see the *SPARC Enterprise T5140 and T5240 Servers Service Manual* for installation instructions.

Note – The list of optional components can be updated without notice. See the product web pages for the most current list of components supported in the server.

ESD Precautions

Electronic equipment is susceptible to damage by static electricity. Use a grounded antistatic wriststrap, footstrap, or equivalent safety equipment to prevent electrostatic damage (ESD) when you install or service the servers.

Caution – To protect electronic components from electrostatic damage, which can permanently disable the system or require repair by service technicians, place components on an antistatic surface, such as an antistatic discharge mat, an antistatic bag, or a disposable antistatic mat. Wear an antistatic grounding strap connected to a metal surface on the chassis when you work on system components.

Installation Overview

This installation guide provides procedures that are to be performed in the following order.

1. Verify that you have received all of the components that ship with your server.
2. Gather configuration information for your system. See your system administrator for specific details, including these parameters:
   - Netmask
   - IP address for the service processor
   - Gateway IP address
3. Install any optional components shipped with your system. If you have purchased other optional components such as additional memory, install them prior to mounting the server in a rack. See "Optional Component Installation" on page 3.
4. Mount the server into a rack or cabinet. See "Installing the Servers in a Rack" on page 15 for both the 1U and 2U servers. Or, if you ordered the express rail rackmounting kit, which has the same rack rail assemblies for both servers, see "Installing the Servers in a Rack With Express Rails" on page 71.

Note – In the rest of this manual, the term *rack* means either an open rack or a closed cabinet.

5. Connect the server to a serial terminal or a terminal emulator (PC or workstation) to display system messages. See "Powering On the System for the First Time" on page 37.

Tip – The serial terminal or a terminal emulator should be connected before you connect the power cables. As soon as AC power is connected to the system, the service processor immediately powers on and runs diagnostics. Diagnostic test failures will be printed on the serial terminal. For more information, refer to the *Integrated Lights Out Manager 2.0 Supplement for SPARC Enterprise T5140 and T5240 Servers*.

6. Connect the data cables to the server, but do not connect the AC power cable yet. See "Connecting the Server Cables for Both Servers" on page 31.

7. Connect the AC power cable to the server and examine the display for any error messages. See "Powering On the System for the First Time" on page 37.

Caution – There is a potential for electric shock if the server and related equipment are not properly grounded.

Note – The service processor runs on the 3.3V standby voltage. As soon as AC power is connected to the system, the service processor immediately powers on, runs diagnostics, and initializes the ILOM firmware.

8. After the service processor boots, access the ILOM command-line interface (CLI) through the serial management port. See "To Log Into the Service Processor Using the Serial Management Port" on page 45.

9. Configure the service processor network addresses. See "To Configure the Service Processor Network Management Port" on page 47.

Note – The service processor network management port is not operational until you configure network settings for the service processor (through the service processor serial management port).

10. Commit the changes to the service processor network parameters. See Step 5 in "To Power On the System for the First Time" on page 38.

11. Power on the server from a keyboard using the ILOM software. See "To Power On the System" on page 51.

12. Configure the Solaris OS. See "Booting the Solaris Operating System" on page 56.

    The Solaris OS is preinstalled on the servers. When you power on, you are automatically guided through the Solaris OS configuration procedure.

13. Install any required patches to the server.

Refer to the *SPARC Enterprise T5140 and T5240 Servers Product Notes* for a list of required patches.

14. Load additional software from the Solaris media kit (optional).

    The Solaris media kit (sold separately) includes several CDs containing software to help you operate, configure, and administer your server. Refer to the documentation provided with the media kit for a complete listing of included software and detailed installation instructions.

Cabling Notes for Both Servers

- **Minimum cable connections for the servers:**
  - At least one system on-board Ethernet network connection (NET port)
  - The service processor serial management port (SER MGT port)
  - The service processor network management port (NET MGT port)
  - Power cables for the two system power supplies
- **Service processor management ports:** There are two service processor management ports for use with the ILOM service processor.
  - The service processor serial management port (labeled SER MGT) uses an RJ-45 cable and is always available. This port is the default connection to the ILOM service processor.
  - The service processor network management port (labeled NET MGT) is the optional connection to the ILOM service processor. This port is not available until you configure network settings for the service processor (through the service processor serial management port). See "Enabling the Service Processor Network Management Port" on page 44. The service processor network management port uses an RJ-45 cable for a 10/100 BASE-T connection. This port does not support connections to Gigabit networks.

  See the *SPARC Enterprise T5140 and T5240 Servers Overview* for more information.

- Ethernet ports are labeled NET0, NET1, NET2, and NET3. The Ethernet interfaces operate at 10 Mbps, 100 Mbps, and 1000 Mbps. TABLE 1-1 shows the transfer rates for the Ethernet ports.

TABLE 1-1 Ethernet Connection Transfer Rates

Connection Type	IEEE Terminology	Transfer Rate
Ethernet	10BASE-T	10 Mbit/sec
Fast Ethernet	100BASE-TX	100 Mbits/sec
Gigabit Ethernet	1000BASE-T	1000 Mbit/sec

- TTYA serial port: Use the DB-9 connector with a null modem cable for serial devices. This port appears as `ttya` in Solaris OS and OpenBoot™ messages. This port is not connected to the service processor serial management port.
- USB Ports: USB ports support hot-plugging. You can connect and disconnect USB cables and peripheral devices while the system is running, without affecting system operations.
  - You can only perform USB hot-plug operations while the OS is running. USB hot-plug operations are not supported when the system `ok` prompt is displayed or before the system has completed booting.
  - You can connect up to 126 devices to each of the four USB controllers, for a total of 504 USB devices per system.
- AC power cables: Do not attach power cables to the power supplies until you have finished connecting the data cables, and have connected the server to a serial terminal or a terminal emulator (PC or workstation). The server goes into Standby mode and the ILOM service processor initializes as soon as the AC power cables are connected to the power source. System messages might be lost after 60 seconds if the server is not connected to a terminal, PC, or workstation.

Port, Connector, and LED Locations for Both Servers

See FIGURE 1-3 and FIGURE 1-4 for the locations of the ports on the SPARC Enterprise T5140 server.

FIGURE 1-3 Rear Panel Cable Connectors and LEDs on the SPARC Enterprise T5140 Server



Figure Legend

1	Power supply 0	**10**	Gbit Enet port NET2
2	Power supply 1	**11**	Gbit Enet port NET3
3	Locator LED button	**12**	USB port 0
4	Service Required LED	**13**	USB port 1
5	Power OK LED	**14**	TTYA serial port
6	Service processor serial management port	**15**	PCIe/XAUI slot 0
7	Service processor network management port	**16**	PCIe/XAUI slot 1
8	Gbit Enet port NET0	**17**	PCIe slot 2
9	Gbit Enet port NET1		

USB ports 2 and 3 are located on the front panel (FIGURE 1-4).

FIGURE 1-4 Front Panel USB Ports on the SPARC Enterprise T5140 Server



Figure Legend

1	System status indicators: Top to bottom: Power button, Power OK LED, Service Required LED, Locator LED Button	**5**	Hard drive HDD3
2	Hard drive HDD0	**6**	USB port 2
3	Hard drive HDD1	**7**	USB port 3
4	Hard drive HDD2		

See FIGURE 1-5 and FIGURE 1-6 for the locations of the ports on the SPARC Enterprise T5240 server.

FIGURE 1-5 Rear Panel Cable Connectors and LEDs on the SPARC Enterprise T5240 Server



Figure Legend

1	Power supply 0	**11**	Gbit Enet port NET3
2	Power supply 1	**12**	USB port 0
3	Locator LED button	**13**	USB port 1
4	Service Required LED	**14**	TTYA serial port
5	Power OK LED	**15**	PCIe slot 3
6	Service processor serial management port	**16**	PCIe or XAUI slot 0
7	Service processor network management port	**17**	PCIe slot 4
8	Gbit Enet port NET0	**18**	PCIe or XAUI slot 1
9	Gbit Enet port NET1	**19**	PCIe slot 5
10	Gbit Enet port NET2	**20**	PCIe slot 2

USB ports 2 and 3 are located on the front panel (FIGURE 1-6).

FIGURE 1-6 Front Panel USB Ports on the SPARC Enterprise T5240 Server



Figure Legend

1	System status indicators: Top to bottom: Power button, Power OK LED, Service Required LED, Locator LED Button	**7**	Hard drive HDD5
2	Hard drive HDD0	**8**	Hard drive HDD6
3	Hard drive HDD1	**9**	Hard drive HDD7
4	Hard drive HDD2	**10**	USB port 2
5	Hard drive HDD3	**11**	USB port 3
6	Hard drive HDD4		

Slide Rail Assembly Notes for Both Servers

The rackmount kit has two *slide rail assemblies*. A slide rail assembly can be installed on either the right or left side of the rack.

Note – The slide rail assemblies are different for the T5140 and T5240 servers. The removable mounting bracket of the SPARC Enterprise T5140 rails slides 13 in. (33 cm) out of the slide rail, then locks in place. The removable mounting bracket of the SPARC Enterprise T5240 rails slide 14 in. (35.5 cm) before locking.

Each slide rail assembly consists of a three-section slide rail and a removable mounting bracket (FIGURE 1-7).

FIGURE 1-7 Sections of the Slide Rail Assembly on the SPARC Enterprise T5240 Server



Figure Legend

1	Mounting bracket	**3**	Middle section
2	Front section	**4**	Rear section

- The *front*, *middle*, and *rear* sections form the *slide rail*. The middle and rear sections have holes for mounting screws, and adjust to fit rack depths from 24 in. (61 cm) to 36.5 in. (93 cm). The front section can be extended to allow movement of the server out of the rack.
- The removable *mounting bracket* slides 14 in. (35.5 cm) out of the slide rail, then locks in place. If you unlock the mounting bracket at this point, it slides an additional 12 in. (30 cm) before separating from the slide rail. You can then mount the mounting bracket to the right or left side of the server chassis.
- Note that there are a total of five locks (FIGURE 1-8) in a slide rail assembly. Four are on the mounting bracket. One lock is on the front section of the slide rail. The installation procedure in Chapter 2 describes the uses of these locks.

FIGURE 1-8 Locating the Locks on the Slide Rail Assembly for the SPARC Enterprise T5240 Server



Cable Management Notes for Both Servers

The same cable management arm (CMA) is included with the rackmounting kit for each server (FIGURE 1-9). The CMA clips onto the slide rails. Use the velcro straps to secure cabling to the CMA.

FIGURE 1-9 Cable Management Arm for Both Servers



Safety Precautions

Caution – Deploy the antitilt bar on the equipment rack before beginning an installation.

Caution – The SPARC Enterprise T5240 server weighs approximately 46 lb (20.7 kg). Two people are required to lift and mount this 2U server into a rack enclosure when using the procedures in this document.



Caution – When completing a two-person procedure, always communicate your intentions clearly before, during, and after each step to minimize confusion.

CHAPTER 2

Installing the SPARC Enterprise T5140 and T5240 Servers

This chapter provides instructions for installing the servers into an equipment rack.

Note – If your rackmount kit came with its own instructions, use the instructions in your rackmount kit instead of the instructions in this chapter. After performing the server installation, proceed to Chapter 3 for first-time power on.

This chapter contains the following sections:

- "Installing the Servers in a Rack" on page 15
- "Installing the Cable Management Arm for Both Servers" on page 24
- "Connecting the Server Cables for Both Servers" on page 31
- "Managing Cables With the CMA" on page 34
- "Dismounting the Servers" on page 35

Note – References to *left* and *right* are from your viewpoint as you face either the front or rear of the equipment.

Installing the Servers in a Rack

Note – Ensure that you have all of the parts in the rackmount kit before you begin the installation of the server.

Note – The procedures in this chapter are the same for both the 1U and 2U servers. The illustrations show a 2U server only as an example.

The rackmount kit (same for both 1U and 2U servers) contains two slide rail assemblies, which can be installed on either the right or left side of the rack. A slide rail assembly consists of two parts: a slide rail and a removable mounting bracket. The slide rail attaches to the rack posts. The mounting bracket attaches to the server chassis. See "Slide Rail Assembly Notes for Both Servers" on page 10 for more information about slide rail assemblies.

▼ To Install the Slide Rail Assemblies

1. **Pull both mounting brackets completely out of their respective slide rails.**

   a. **Simultaneously press and hold the upper and lower lock buttons of the slide rail lock (**FIGURE 2-1**).**

FIGURE 2-1 Unlocking the Slide Rail Assembly (Either Server)



   b. **Pull the mounting bracket out until it locks in the extended position.**

c. Slide the mounting bracket release button in the direction shown in FIGURE 2-2, then slide the mounting bracket out of the slide rail.

FIGURE 2-2 Location of the Mounting Bracket Release Button (Either Server)



d. Press the metal lever (labeled Push) on the middle section (FIGURE 2-3) of the sliding rail, then push the middle section back into the rack.

FIGURE 2-3 Unlocking the Slide Rail Middle Section (Either Server)



2. **Attach a mounting bracket to the right side of the chassis.**

    a. **Position the mounting bracket against the chassis (**FIGURE 2-4**). Ensure that the slide rail lock is at the front and the three keyed openings on the mounting bracket are aligned with the three locating pins on the side of the chassis.**

FIGURE 2-4 Attaching a Mounting Bracket to the Chassis (Either Server)



b. Ensure that the heads of the locating pins protrude though the keyed openings in the mounting bracket. Pull the mounting bracket toward the front of the chassis until the bracket locks into place with an audible click.

c. Verify that all locating pins are trapped in the keyed openings and that the correct locating pin has engaged the mounting bracket lock. See the right side of FIGURE 2-4**.**

3. Attach the second mounting bracket to the left side of the chassis.

4. Determine which rack hole numbers to use when attaching the slide rails to the rack posts.

If the server is two rack units high (2U), the slide rails occupy the lower half of the 2U space.

5. Determine which screws you will use to mount the slide rails.

- If your rack has threaded mounting holes in the rack posts, determine whether the threads are metric or standard. Select the appropriate screws from the package included in the mounting kit.

- If your rack does not have threaded mounting holes, the mounting screws are secured with a caged nut.

6. **Attach a slide rail to the right front rack post.**

   a. **Loosely attach the front of a slide rail to the right front rack post using two screws (**FIGURE 2-5**).**

Note – Do not tighten the screws yet.

FIGURE 2-5 Mounting a Slide Rail (Either Server)



   b. **Adjust the length of the slide rail by sliding the rear mounting flange to reach the outside edge of the rear rack post.**

   c. **Loosely attach the rear of the slide rail to the rear rack post with two screws.**

7. **Attach the second slide rail to the left rack posts in a similar manner. Do not tighten the screws.**

8. **Use the slide rail spacing tool to adjust the distance between the slide rails.**

   a. **At the front of the rack, plug the left side of the tool into slots at the end of the left rail (**FIGURE 2-6**).**

FIGURE 2-6 Using the Slide Rail Spacing Tool to Adjust the Distance Between the Slide Rails (Either Server)



   b. **Insert the right side of the tool into the front end of the right rail.**

   c. **Slide the end of the rail to the right or left as needed to allow the ends of the tool to enter the ends of both rails.**

      The distance between the rails is now equal to the width of the server with mounting brackets.

   d. **Tighten the screws to lock the ends of the rails in place.**

   e. **At the rear of the rack, repeat** Step a **through** Step d**. for the rear ends of the rails.**

▼ To Insert and Lock the Server in the Rack

1. **Deploy the antitilt bar, if the chassis or rack is so equipped.**

Caution – The weight of the servers on extended slide rails can be enough to overturn an equipment rack.

Caution – The 2U server weighs approximately 46 lb (20.7 kg). Two people are required to lift and mount the server into a rack enclosure when using the procedures in this chapter.

---

2. **Insert the ends of the mounting brackets into the sliding rails (**FIGURE 2-7**).**

FIGURE 2-7 Mounting the Chassis on the Slide Rails (Either Server)



3. **Slide the chassis into the rack.**

Caution – Before continuing, verify that the server is securely mounted in the rack, and that the slide rails are locked to the mounting brackets.

Installing the Cable Management Arm for Both Servers

The rackmounting kit for each server comes with the same cable management arm (CMA) assembly. The CMA installation and cable management procedures are the same for both servers. See "Cable Management Notes for Both Servers" on page 13 for more information on the cable management arm.

Note – The CMA includes velcro straps to secure the cables inside the CMA. Do not install the velcro straps until you install the CMA, connect the cables, and place the cabling inside the CMA as described in the following procedures.

▼ To Install the Cable Management Arm

Caution – Support the CMA during this installation. Do not allow the assembly to hang by its own weight until it is secured by all three attachment points.

1. **Remove the tape from the CMA rail extension (on the left of the CMA) and remove the CMA rail extension.**

2. **Attach the CMA rail extension to rear left slide rail (**FIGURE 2-8**).**

   At the rear of the rack, plug the CMA rail extension into the end of the left sliding rail assembly. The tab at the front of the rail extension clicks into place.

FIGURE 2-8 Inserting the CMA Rail Extension Into the Rear of the Left Slide Rail (Either Server)



The right sides of the two CMA arms have hinged extensions. On the manufacturer's instruction sheet, the smaller extension is called the CMA Connector for Inner Member. This extension attaches to the right mounting bracket. The larger extension is called the CMA Connector for Outer Member, and attaches to the right sliding rail.

3. **Insert the smaller extension into the clip located at the end of the mounting bracket (**FIGURE 2-9**).**

   Slide the smaller extension into the square hole on the middle-in-width of the clip that is located at the end of the mounting bracket.

FIGURE 2-9 Mounting the Inner CMA Connector (Either Server)



4. **Insert the larger extension into the end of the right sliding rail (**FIGURE 2-10**).**

FIGURE 2-10 Attaching the Outer CMA Connector (Either Server)



5. **Insert the hinged plastic connector at the left side of the CMA fully into the CMA rail extension (**FIGURE 2-11**).**

   The plastic tab on the CMA rail extension locks the hinged plastic connector in place.

FIGURE 2-11 Mounting the Left Side of the Slide Rail (Either Server)



▼ To Verify the Operation of the Slide Rails and the CMA

Tip – Two people are needed for this procedure, one to move the server in and out of the rack, and one to observe the cables and CMA.

1. **For a free-standing rack, deploy the antitilt bar.**
2. **Unlock the slide lock buttons (FIGURE 2-12) at the right and left sides of the chassis.**
3. **Slowly pull the server out of the rack until the slide rails reach their stops.**

FIGURE 2-12 Unlocking the Slide Rail Assembly (Either Server)



4. **Inspect any attached cables for binding or kinks.**
5. **Verify that the CMA extends fully and does not bind in the slide rails.**
6. **Verify that the server extends fully and locks in the maintenance position.**
   The server should stop after approximately 15 inches (40 cm) of travel.

7. **Pull both slide rail release buttons toward you simultaneously and slide the server back into the rack (**FIGURE 2-13**).**

   The server should slide smoothly into the rack without binding.

FIGURE 2-13 Rail Mounting Bracket Release Button (Either Server)



8. **Verify that the CMA retracted without binding.**
9. **Adjust the cable straps and CMA as required to secure the cables.**

   See "Managing Cables With the CMA" on page 34.

Connecting the Server Cables for Both Servers

To boot the server, you must connect and configure the network and serial ports. The procedures are given in the following sections.

- "To Connect the Service Processor Serial Management Port" on page 31
- "To Connect the Service Processor Network Management Port" on page 32
- "To Connect the Ethernet Network Cables" on page 33
- "To Connect the AC Power Cable to the Server" on page 34

The servers also have serial and USB ports available for connections to optional devices. See "Port, Connector, and LED Locations for Both Servers" on page 7 for more information.

Note – When you are finished connecting the cables to the server, ensure that the server can slide smoothly in and out of the rack without binding or damaging the cables. See the section, "To Verify the Operation of the Slide Rails and the CMA" on page 29.

▼ To Connect the Service Processor Serial Management Port

The service processor serial management port is marked SER MGT (FIGURE 2-14). This port is the farthest left RJ-45 port on the rear panel.

Note – The cable and DB-9 RJ-45 adapters are for the host serial port, and not for the server SER MGT port.

FIGURE 2-14 Service Processor Serial Management Port – Rear Panel



Use this port for server management. This port is needed to set up the service processor network management port, as detailed in "Enabling the Service Processor Network Management Port" on page 44.

Note – Use the service processor serial management port *only* for server management. It is the default connection between the service processor and a terminal or a computer.

Caution – Do not attach a modem to this port.

- **Connect a Category 5 cable from the SER MGT serial management port to the terminal device.**

  When connecting either a DB-9 or a DB-25 cable, use an adapter to perform the crossovers given for each connector.

▼ To Connect the Service Processor Network Management Port

The service processor network management port is labeled NET MGT (FIGURE 2-15). This port is located just to the right of the serial management (SER MGT) port on the rear panel.

FIGURE 2-15 Service Processor Network Management Port – Rear Panel



Note – This port is not operational until you configure the network settings (through the serial management port), as detailed in "To Configure the Service Processor Network Management Port" on page 47.

Note – If you have access to a DHCP server on the network, you can see the service processor get an IP address because the DHCP client is enabled by default.

Note – The service processor network management port is configured by default to retrieve network settings with Dynamic Host Configuration Protocol (DHCP) and allow connections using Solaris Secure Shell (SSH). You might need to modify these settings for your network. Instructions are given in Chapter 3.

- **Connect a Category 5 cable from the NET MGT network management port to your network switch or hub.**

▼ To Connect the Ethernet Network Cables

The server has four network connectors, marked NET0, NET1, NET2, and NET3 (FIGURE 2-16). These connectors are RJ-45 Gigabit Ethernet.

FIGURE 2-16 Service Processor Ethernet Network Ports – Rear Panel



1. **Connect a Category 5 cable from your network switch or hub to Ethernet Port 0 (**NET**0) on the rear of the chassis.**

   NET**0** is the farthest left port in the 4-port network cluster in FIGURE 2-16.

2. **Connect Category 5 cables from your network switch or hub to the remaining Ethernet ports (**NET**1,** NET**2,** NET**3), as needed.**

▼ To Connect the AC Power Cable to the Server

Powering on the system for the first time requires special preparation and procedures. For example, if you have not prepared a display before connecting the AC power cable, system messages might be lost.

Caution – Finish the hardware procedures in this chapter, but do not attach the AC power cable yet.

Powering on the system for the first time requires special preparation and procedures. For example, if you have not prepared a display before connecting the AC power cable, system messages could be lost.

Caution – The server goes into Standby mode and the service processor initializes as soon as the AC power cable is connected to the power source.

- **Go to** "Powering On the System for the First Time" on page 37 **for instructions on connecting the server to AC power.**

Managing Cables With the CMA

Managing the cables with the CMA is the same for both servers.

▼ Securing the Server Cables in the CMA

- **Once the server cables are connected and placed inside the CMA, open the velcro cable straps and wrap the straps around the CMA securing the cables inside the CMA. (**FIGURE 2-17**).**

FIGURE 2-17 Securing the Server Cables With the CMA and Velcro Straps (Either Server)



Caution – Verify the operation of the slide rails and CMA, and cable service loops. Perform the steps in the following procedure again before continuing: "To Verify the Operation of the Slide Rails and the CMA" on page 29.

Dismounting the Servers

To install or replace internal parts in the server, you must first remove the server from the rack. For the removal procedure, refer to the *SPARC Enterprise T5140 and T5240 Servers Service Manual*.

CHAPTER 3

Powering On the System

This chapter includes instructions for booting the servers and for enabling the service processor network management port.

This chapter contains the following topics:

- "Powering On the System for the First Time" on page 37
- "Enabling the Service Processor Network Management Port" on page 44
- "Logging Into the Service Processor" on page 45
- "Using the Service Processor for Common Operations" on page 50
- "Booting the Solaris Operating System" on page 56
- "Verifying System Functionality" on page 59

Powering On the System for the First Time

This section provides an overview and instructions for powering on your system the first time.

ILOM System Console

When you power on the system, the boot process begins under the control of the Integrated Lights Out Manager (ILOM) system console. The system console displays status and error messages generated by firmware-based tests during system startup.

Note – To see these status and error messages, connect a terminal or terminal emulator to the serial management port (SER MGT). For a basic procedure to connect a terminal or terminal emulator, see "To Power On the System for the First Time" on page 38.

For a more detailed discussion on configuring the system console and connecting terminals, refer to the *SPARC Enterprise T5140 and T5240 Servers Administration Guide*.

ILOM Service Processor

After the system console finishes its low-level system diagnostics, the ILOM service processor initializes and runs a higher level of diagnostics. When you access the ILOM service processor using a device connected to the serial management port, you see the output of the ILOM diagnostics.

By default, the service processor configures the network management port automatically, retrieving network configuration settings using the Dynamic Host Configuration Protocol (DHCP) and allowing connections using Secure Shell (SSH).

Note – If you are unable to use DHCP on your network, you must connect to the ILOM service processor using the serial management port to configure the network management port for your network. See "To Configure the Service Processor Network Management Port" on page 47.

▼ To Power On the System for the First Time

1. **Confirm that you have completed all of the preparations for installation.**

   See the instructions in Chapter 1.

2. **Confirm that you have completed the installation of the server in its rack.**

   See the instructions in Chapter 2.

3. **Connect a terminal or a terminal emulator (PC or workstation) to the service processor serial management port.**

   Configure the terminal or terminal emulator with these settings:

- 9600 baud
- 8 bits
- No parity
- 1 Stop bit

- No handshake

A null modem configuration is needed, meaning the transmit and receive signals are reversed (crossed over) for DTE to DTE communications. You can use the supplied RJ-45 crossover adapters with a standard RJ-45 cable to achieve the null modem configuration.

Note – When you power on the server for the first time and you do not have a terminal or terminal emulator (PC or workstation) connected to the service processor serial management port, you will not see system messages.

FIGURE 3-1 Server Connections



4. **(Optional) Connect an Ethernet cable between the server's Net MGT port (FIGURE 3-1) and the network to which future connections to the SP and host will be made.**

   After the initial configuration of the system using the SP SER MGT port, communication with the SP and host is usually performed through this Ethernet interface.

5. **Connect an Ethernet cable between one of the server's NET ports (FIGURE 3-1) and the network to which the server will communicate.**

6. **Plug the power cords into the power supplies and into a power source.**

Note – Only one power connection is required for operation. Use two power connections for redundancy.

The service processor runs on the 3.3V standby voltage. As soon as AC power is connected to the system, the service processor powers on, runs diagnostics, and initializes the ILOM firmware.

After a few minutes, the SP login prompt appears on the terminal device. The host is not initialized or powered on yet.

7. **At the terminal device, log in to the SP as** `root` **with a password of** `changeme`**.**

```
XXXXXXXXXXXXXXXX login: root
Password: changeme
. . .
->
```

After a brief delay, the SP prompt is displayed (`->`). At this point, there are many commands you can perform using the Integrated Lights Out Manager interface.

Additional SP information, such as how to change the password and how to set up the SP network parameters is available in the online documentation set.

8. **Power on the server and redirect the host output to display on the serial terminal device:**

```
-> start /SYS
Are you sure you want to start /SYS (y/n)? y
-> start /SP/console
Are you sure you want to start /SP/CONSOLE (y/n)? y
Serial console started. To stop, type #.
. . .
```

After you start the SP console, the server initialization takes approximately 20 minutes to complete.

9. **When prompted, follow the onscreen instructions for configuring the Solaris Operating System on your host and enter the following configuration information.**

   You will be prompted to confirm the configuration several times, enabling confirmation and changes. If you are not sure how to respond to a particular value, you can accept the default, and make future changes when the Solaris OS is running.

Parameter	Description
Language	Select a number from the displayed language list.
Locale	Select a number from the displayed locale list.
Terminal Type	Select a terminal type that corresponds with your terminal device.
Network?	Select Yes.
Multiple Network Interfaces	Select the network interfaces that you plan to configure. If you are not sure, select the first one in the list.
DHCP?	Select Yes or No according to your network environment.
Host Name	Enter the host name for the server.
IP Address	Enter the IP address for this Ethernet interface.
Subnet?	Select Yes or No according to your network environment.
Subnet Netmask	(If subnet was Yes) Enter the netmask for the subnet for your network environment.
IPv6?	Specify whether or not to use IPv6. If you are not sure, select No to configure the Ethernet interface for IPv4.
Security Policy	Select either standard UNIX security (No) or Kerberos Security (Yes). If you are not sure, select No.
Confirm	Review the onscreen information and change it if needed. Otherwise, continue.
Name Service	Select the name service according to your network environment. Note–If you select a name service other than None, you will be prompted for additional name service configuration information.
NFSv4 Domain Name	Select the type of domain name configuration according to your environment. If you are not sure, select `Use the NFSv4 domain derived by the system`.
Time Zone (Continent)	Select your continent.
Time Zone (Country or Region)	Select your country or region.

Time Zone	Select the time zone.
Date and Time	Accept the default date and time or change the values.
root Password	Enter the `root` password twice. This password is for the superuser account for the Solaris OS on this server. This password is not the SP password.

10. Log in to the server and explore its capabilities.

There are many commands you can use to verify the functionality of the system. The following list describes a few of them:

- `showrev` – Displays the hostname and system architecture information. Use the `-a` option with this command to see the patches that are installed.
- `psrinfo` – Displays information about the number and status of the processors and cores in the host.
- `prtdiag` – Displays system configuration and diagnostic information.

Review the Solaris OS man pages and documentation for more details.

Enabling the Service Processor Network Management Port

The service processor network management port is not operational unless your network employs DHCP, in which case the configuration in automatic. If you network uses DHCP, you can run this command

```
-> show /SP/network
```

to view your server's network configuration information. For example,

```
-> show /SP/network

  /SP/network
     Targets:

     Properties:
         commitpending = (Cannot show property)
         dhcp_server_ip = 10.8.31.5
         ipaddress = 10.8.31.188
         ipdiscovery = dhcp
         ipgateway = 10.8.31.248
         ipnetmask = 255.255.252.0
         macaddress = 00:14:4F:7E:83:4F
         pendingipaddress = 10.8.31.188
         pendingipdiscovery = dhcp
         pendingipgateway = 10.8.31.248
         pendingipnetmask = 255.255.252.0
         state = enabled

     Commands:
         cd
         set
         show
```

If your network does *not* use DHCP, the network management port is not operational until you configure network settings for the service processor. Configure the service processor in this order:

1. After the service processor boots, access the ILOM CLI through the serial management port. See "To Log Into the Service Processor Using the Serial Management Port" on page 45.

2. Configure the service processor. See "To Configure the Service Processor Network Management Port" on page 47.

3. Commit the changes to the service processor parameters. See Step 5 in "To Configure the Service Processor Network Management Port" on page 47.

You can now use the network management port at any time to access the service processor. See "To Log Into the Service Processor Using the Network Management Port" on page 50.

Logging Into the Service Processor

If you are powering on the system for the first time after installation, use the service processor serial port to power on the system and run POST. See "To Log Into the Service Processor Using the Serial Management Port" on page 45.

If the network management port has already been configured, you can use it instead of the serial management port. See "To Log Into the Service Processor Using the Network Management Port" on page 50.

▼ To Log Into the Service Processor Using the Serial Management Port

After the service processor boots, access the ILOM CLI to configure and manage the system. The ILOM CLI prompt (`->`) is displayed at the first time the service processor is booted. The default configuration provides an ILOM CLI `root` user account. The default `root` password is *changeme*. Change the password using the service processor ILOM CLI `password` command.

1. **If this is the first time the system has been powered on, use the** `password` **command to change the** `root` **password.**

```
...
Starting OpenBSD Secure Shell server: sshd.
Starting Servicetags listener: stlistener.
Starting FRU update program: frutool.

hostname login: root
Password: changeme

Copyright 2007 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
...
Federal Acquisitions: Commercial Software -- Government Users
Subject to Standard License Terms and Conditions.
...

Warning: password is set to factory default.

-> set /SP/users/root password
Enter new password: ********
Enter new password again: ********

->
```

Note – After the `root` password has been set, on subsequent reboots, the ILOM CLI login prompt is displayed.

2. **Enter** `root` **for the login name followed by your password.**

```
...
hostname login: root
Password: password (nothing displayed)
Waiting for daemons to initialize...

Daemons ready

Integrated Lights Out Manager

Version 2.0.0.0

Copyright 2007 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.

->
```

▼ To Configure the Service Processor Network Management Port

Note – If your network allows the use of DHCP, this configuration is performed automatically the first time you boot the system.

Use this procedure only when:

- You are unable to use DHCP on your network.
- You need to modify the ILOM service processor network management port settings.

In this procedure, you connect to the ILOM service processor using the serial management port to manually reconfigure the network management port.

Note – For more information on configuring ILOM, refer to the *Integrated Lights Out Manager 2.0 Supplement for SPARC Enterprise T5140 and T5240 Servers.*

Set these network parameters according to the specific details of your network configuration:

- `/SP/network state` – Specifies whether the service processor is on the network or not
- `/SP/network pendingipaddress` – IP address of the service processor
- `/SP/network pendingipgateway` – IP address of the gateway for the subnet
- `/SP/network pendingipnetmask` – Netmask for the service processor subnet
- `/SP/network pindingipdiscovery` - Specifies whether the service processor uses DHCP or static IP address assignment
- `/SP/network commitpending` - Commits the service processor to use the pending settings

Configure these parameters with the `set` command. The usage is as follows: `set` *target property=value* where `/SP/network` is the target and `pendingipaddress=`*xxx.xxx.xxx.xxx*, for example, is the *property=value*.

3. **Configure the service processor using information from your network administrator.**

   Your choices are

   - `dhcp` - Set up the network connection with a dynamically created IP configuration.
   - `static` - Set up the network connection with a static IP configuration.

a. If you choose to use a dynamically created IP address (use DHCP to retrieve the network setting), **set** `pendingipdiscovery` **to** `dhcp`**.**

```
-> set /SP/network pendingipdiscovery=dhcp
Set 'pendingipdiscovery' to 'dhcp'
```

a. If you choose to configure a static IP configuration. **set the parameters** `pendingipdiscovery`**,** `pendingipaddress`**,** `pendingipgateway`**, and** `pendingipnetmask` **as follows.**

i. Set the service processor to accept a static IP address.

```
-> set /SP/network pendingipdiscovery=static
Set 'pendingipdiscovery' to 'static'
```

ii. Set the IP address for the service processor.

```
-> set /SP/network pendingipaddress=service-processor-IPaddr
Set 'pendingipaddress' to 'service-processor-IPaddr'
```

iii. Set the IP address for the service processor gateway.

```
-> set /SP/network pendingipgateway=gateway-IPaddr
Set 'pendingipgateway' to 'gateway-IPaddr'
```

iv. Set the netmask for the service processor.

```
-> set /SP/network pendingipnetmask=255.255.255.0
Set 'pendingipnetmask' to '255.255.255.0'
```

This example uses `255.255.255.0` to set the netmask. Your network environment subnet might require a different netmask. Use a netmask number most appropriate to your environment.

4. Use the `show /SP/network` **command to verify that the parameters were set correctly.**

CODE EXAMPLE 3-1 shows parameters that have been set to convert a service processor from a dhcp configuration to a static configuration

CODE EXAMPLE 3-1 `show /SP/network` Command Output

```
-> show /SP/network
  /SP/network
     Targets:
```

CODE EXAMPLE 3-1 `show /SP/network` Command Output

```
      Properties:
          commitpending = (Cannot show property)
          dhcp_server_ip = xxx.xxx.xxx.xxx
          ipaddress = xxx.xxx.xxx.xxx
          ipdiscovery = dhcp
          ipgateway = xxx.xxx.xxx.xxx
          ipnetmask = 255.255.252.0
          macaddress = 00:14:4F:3F:8C:AF
          pendingipaddress = xxx.xxx.xxx.xxx
          pendingipdiscovery = static
          pendingipgateway = xxx.xxx.xxx.xxx
          pendingipnetmask = 255.255.255.0
          state = enabled
      Commands:
          cd
          set
          show
->
```

Note – After setting the configuration parameters, you must enter the `set /SP/network commitpending=true` command for the new values to take affect.

---

5. Commit the changes to the service processor network parameters.

```
-> set /SP/network commitpending=true
Set 'commitpending' to 'true'
```

Note – You can run the `show /SP/network` command again (after performing the `set /SP/network commitpending=true` command) to verify that the parameters have been updated.

▼ To Log Into the Service Processor Using the Network Management Port

Note – You must configure the service processor parameters shown in "To Configure the Service Processor Network Management Port" on page 47 before you can use the network management port.

- **Open an SSH session and connect to the service processor by specifying its network address.**

```
% ssh root@xx.xxx.xx.x
...
Are you sure you want to continue connecting (yes/no)? yes
...
Password: password (nothing displayed)
Waiting for daemons to initialize...

Daemons ready

Integrated Lights Out Manager

Version 2.0.0.0

Copyright 2007 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.

->
```

Using the Service Processor for Common Operations

Note – For more information on using the ILOM service processor, refer to the *Integrated Lights Out Manager 2.0 Supplement for SPARC Enterprise T5140 and T5240 Servers.*

▼ To Power On the System

1. **Perform the following steps to verify that there are no faults:**

   a. **Set the virtual keyswitch to** `diag` **mode so that POST will run in Service mode.**

```
-> set /SYS keyswitch_state=diag
Set 'keyswitch_state' to 'diag'
```

   b. **To initiate the power on sequence, type the** `start /SYS` **command.**

   You will see an ILOM CLI alert message on the system console. This message indicates that the system has reset.

```
-> start /SYS
Are you sure you want to start /SYS (y/n)? y
Starting /SYS

->
```

c. **Switch to the system `console` to view POST output.**

```
-> start /SP/console
Are you sure you want to start /SP/console (y/n)? y
Serial console started.  To stop, type #.
.
.
.
```

Watch the POST output for possible fault messages. The following output is a sign that POST did not detect any faults:

```
.
.
.
2007-12-14 16:34:53.385 0:1:0>INFO:
2007-12-14 16:34:53.391 0:1:0>  POST Passed all devices.
2007-12-14 16:34:53.399 0:1:0>POST:     Return to VBSC.
2007-12-14 16:34:53.406 0:1:0>Master set ACK for vbsc runpost
command and spin.
...
SPARC Enterprise T5240, No Keyboard
Copyright 2007 Sun Microsystems, Inc.  All rights reserved.
OpenBoot 4.27.x, 3968 MB memory available, Serial #74409918.
Ethernet address 0:14:4f:6f:67:be, Host ID: 846f67be.


{8} ok
```

2. **Type the console escape sequence (by default `#.` (Hash-Period)) to return to the ILOM prompt.**

3. **Check the POST execution result with the following command:**

```
-> show /SP/faultmgmt -level all
```

Note – Depending on the configuration of ILOM, POST variables, and whether POST detected faults or not, the server might boot, or the system might remain at the `ok` prompt. If the system is at the `ok` prompt, type `boot`.

---

4. **Use the** `set /SYS keyswitch_state=normal` **command to return the virtual keyswitch to Normal mode (default) so that the system can power on and start the boot process.**

```
-> set /SYS keyswitch_state=normal
Set 'keyswitch_state' to 'normal'
```

▼ To Connect to the System Console

Output from POST, OpenBoot, and the Solaris OS is displayed in the system console using the network console on the service processor.

- **Type the** `start /SP/console` **command.**

  Multiple users can be connected to the console, but only one can be attached.

```
-> start /SP/console
Are you sure you want to start /SP/console (y/n)? y
Serial console started.  To stop, type #.
```

Note – For more information about POST output, refer to the *SPARC Enterprise T5140 and T5240 Servers Service Manual*.

▼ To Perform a Normal System Initialization

1. **Issue the** `start /SYS` **command .**

```
-> start /SYS
Are you sure you want to start /SYS (y/n)? y
Starting /SYS
```

2. **To initiate the power on sequence, type the** `start /SYS` **command.**

   You will see an ILOM CLI alert message on the system console. This message indicates that the system has reset..

```
-> start /SP/console
Are you sure you want to start /SP/console (y/n)? y
Serial console started.  To stop, type #.
```

The CPU and memory controllers initialize, and eventually OpenBoot initializes. After a number of system console messages, the `ok` prompt appears, or the system will boot into the Solaris OS.

Note – System behavior depends on how the `auto-boot` variable is set. See the *SPARC Enterprise T5140 and T5240 Servers Service Manual* for more information.

The following example output is a small section of the complete output.

```
0:1:0>
0:1:0>SPARC-Enterprise[TM] T5140/T5240 POST 4.27.x.
2007/12/11 18:55

...

0:1:0>Network Interface Unit Tests....Done
0:1:0>Functional CPU Tests....Done
0:1:0>Extended Memory Tests....Done
2007-12-14 16:45:28.800 0:1:0>INFO:
2007-12-14 16:45:28.806 0:1:0>  POST Passed all devices.
2007-12-14 16:45:28.816 0:1:0>POST:     Return to VBSC.
2007-12-14 16:45:28.824 0:1:0>Master set ACK for vbsc runpost
command and spin...


SPARC Enterprise T5240, No Keyboard
Copyright 2007 Sun Microsystems, Inc.  All rights reserved.
OpenBoot 4.27.x, 3968 MB memory available, Serial #74409918.
Ethernet address 0:14:4f:6f:67:be, Host ID: 846f67be.


{0} ok
```

Devices in the OpenBoot Device Tree

TABLE 3-1 Disk Slot Numbers, Logical Device Names, and Physical Device Names

Disk Slot Number	Logical Device Name*	Physical Device Name
Slot 0	`c0t0d0`	`/devices/pci@0/pci@0/pci@2/scsi@0/sd@0,0`

TABLE 3-1 Disk Slot Numbers, Logical Device Names, and Physical Device Names *(Continued)*

Disk Slot Number	Logical Device Name*	Physical Device Name
Slot 1	c0t1d0	/devices/pci@0/pci@0/pci@2/scsi@0/sd@1,0
Slot 2	c0t2d0	/devices/pci@0/pci@0/pci@2/scsi@0/sd@2,0
Slot 3	c0t3d0	/devices/pci@0/pci@0/pci@2/scsi@0/sd@3,0

* The logical device names might appear differently on your system, depending on the number and type of add-on disk controllers installed.

TABLE 3-2 Device Identifiers and Devices

Device Identifiers	Devices
/SYS/MB/CMP*cpu_number*/P*strand_number*	CMP (0-1) CPU strand (0-63)
/SYS/MB/CMP*n*/RISER*n*/PCIE*slot_number*	CMP (0-1) Riser (0-1) PCIe slot (0-5)
/SYS/MB/CMP*n*/RISER*n*/XAUI*card_number*	CMP (0-1) Riser (0-1) XAUI card (0-1)
/SYS/MB/NET*network_number*	Network interfaces (0-3)
/SYS/MB/PCIE	PCIe root complex
/SYS/MB/USB*number*	USB ports (0-1, located on rear of chassis)
/SYS/MB/CMP*n*/L2_BANK*number*	CMP (0-1) Bank (0-7)
/SYS/DVD	DVD
/SYS/USBBD/USB*number*	USB ports (2-3, located on front of chassis)
/SYS/TTYA	DB9 Serial Port
/SYS/MB/CMPn/MRn/BR/*branch_number*/CH*channel_number*/D*dimm_number*	CMP (0-1) Riser (0-1) Branch (0-1) Channel (0-1) DIMM (0-3)

Booting the Solaris Operating System

The Solaris OS is preinstalled on the servers on the disk in slot 0. The Solaris OS is not configured (that is, the `sys-unconfig` command was run in the factory). If you boot the system from this disk, you will be prompted to configure the Solaris OS for your environment.

▼ To Boot the Solaris Operating System

1. **At the `ok` prompt, boot from the disk that contains the Solaris OS.**

- If you know which disk to boot from, skip this step and perform Step 2.
- If you need to determine which disk to boot from, issue the `show-disks` command at the `ok` prompt to see the path to the configured disks, similar to the following:

```
ok show-disks
a) /pci@0/pci@0/pci@2/scsi@0/disk
b) /pci@0/pci@0/pci@1/pci@0/pci@1/pci@0/usb@0,2/storage@2/disk
q) NO SELECTION Enter Selection, q to quit: q
ok
```

2. **Type the `boot` command at the `ok` prompt.**

   Use the value from Step 1 to construct the `boot` command. You must append the target to the disk path.

   In the following example, the server is booted from disk 0 (zero) on a SPARC Enterprise T5140 server.

```
ok boot disk0

Boot device: /pci@0/pci@0/pci@2/scsi@0/disk@0  File and args:
SunOS Release 5.10 Version Generic_127127-03 64-bit
Copyright 1983-2007 Sun Microsystems, Inc.  All rights reserved.
Use is subject to license terms.
Hostname: hostname
NIS domain name is x.x.x.x

hostname console login:
```

▼ To Avoid Booting the Solaris Operating System at Start Up

In hard drive HDD0, the Solaris OS is preinstalled.

- **If you do not want to start the preinstalled OS, set the Open Boot PROM parameter `auto-boot?` to `false`. For example:**

```
-> set /HOST/bootmode script="setenv auto-boot? false"
```

▼ To Reset the System

- **If it is necessary to reset the system, use the** `shutdown -g0 -i6 -y` **command.**

```
# shutdown -g0 -i6 -y
```

It is not necessary to power the system off and on to simply reset the system.

▼ To Power Cycle the System

If a simple reset does not clear a system problem, you can power the system off and on with this procedure.

1. **Shut down the Solaris OS.**

   At the Solaris OS prompt, type the `shutdown -g0 -i0 -y` command. Then type `h` when prompted to halt the Solaris OS and to return to the `ok` prompt.

```
# shutdown -g0 -i0 -y
# svc.startd: The system is coming down.  Please wait.
svc.startd: 91 system services are now being stopped.
Jun 12 19:46:57 wgs40-58 syslogd: going down on signal 15
svc.startd: The system is down.
syncing file systems... done
Program terminated
r)eboot, o)k prompt, h)alt?
```

2. **Switch from the system console prompt to the service processor console prompt by issuing the console escape sequence (by default,** `#.` **(Pound-Period)).**

```
ok #.
->
```

3. **Using the ILOM CLI, type the** `stop /SYS` **command to perform a graceful shutdown of the system.**

```
-> stop /SYS
Are you sure you want to stop /SYS (y/n)? y
Stopping /SYS

->
```

Note – To perform an immediate and ungraceful shutdown, use the `stop -force -script /SYS` or `stop -script /SYS` commands. These commands stop everything immediately, ensure that all data is saved before entering these commands.

4. **Type the `start /SYS` command.**

```
-> start /SYS
Are you sure you want to start /SYS (y/n)? y
Starting /SYS

->
```

Note – To force a power-on sequence, use the `start -script /SYS` command.

5. **Reconnect to the system console with the `start /SP/console` command.**

```
-> start /SP/console
Are you sure you want to start /SP/console (y/n)? y
Serial console started.  To stop, type #.
```

The systems displays various messages, followed by the `ok` prompt.

Verifying System Functionality

After powering on the system for the first time, you can use the Sun Validation Test Suite (SunVTS™) software to verify the functionality and performance of any installed components, as well as its network connections. Refer to the SunVTS documentation at `http://www.sun.com/documentation` for more information.

APPENDIX **A**

Updating the Firmware

This appendix provides instructions for updating SP firmware.

- "The `flashupdate` command" on page 61
- "Updating the Firmware" on page 61

The `flashupdate` command

The `flashupdate` command updates both the service processor firmware and the server firmware.

The flash image consists of the following components:

- Service processor firmware
- OpenBoot
- POST
- Reset/config
- Sequencer
- Partition description

Updating the Firmware

To use the features and fixes in subsequent firmware releases, perform "To Update the Firmware" on page 62.

▼ To Update the Firmware

1. **Ensure that the ILOM service processor network management port is configured.**

   This configuration is required to access the new flash image over the network. See "To Configure the Service Processor Network Management Port" on page 47.

2. **Open an SSH session to connect to the service processor.**

```
% ssh root@xx.xxx.xx.x
...
Are you sure you want to continue connecting (yes/no)? yes
...
Password: password (nothing displayed)
Waiting for daemons to initialize...

Daemons ready

Integrated Lights Out Manager

Version 2.0.0.0

Copyright 2007 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.

->
```

3. **Verify that the host is powered off.**

   If the host is not powered off, type the `stop /SYS` command.

```
-> stop /SYS
```

4. **Verify that the `keyswitch_state` parameter is set to `normal`.**

```
-> set /SYS keyswitch_state=normal
```

5. **Type the `load` command.**

   The `load` command updates the service processor flash image and the host firmware. The `load` command requires the following information:

- IP address of a TFTP server on the network that can access the flash image

- Full path name to the flash image that the IP address can access

  The command usage is as follows:

  `load [-script] -source tftp://`*`xxx.xxx.xx.xx/pathname`*

  where:

- `-script` – Does not prompt for confirmation and acts as if yes was specified
- `-source` – Specifies the IP address and full path name (URI) to the flash image

```
-> load -source tftp://xxx.xxx.xx.xx/pathname
 NOTE: A firmware upgrade will cause the server and ILOM to
       be reset. It is recommended that a clean shutdown of
       the server be done prior to the upgrade procedure.
       An upgrade takes about 6 minutes to complete. ILOM
       will enter a special mode to load new firmware. No
       other tasks can be performed in ILOM until the
       firmware upgrade is complete and ILOM is reset.

Are you sure you want to load the specified file (y/n)? y
Do you want to preserve the configuration (y/n)? y
.............................................................

Firmware update is complete.
ILOM will now be restarted with the new firmware.
Update complete. Reset device to use new image.

->
```

After the flash image has been updated, the system will automatically reset.

The service processor resets, runs diagnostics, and returns to the login prompt (on the serial console), similar to CODE EXAMPLE A-1.

CODE EXAMPLE A-1 Typical Boot Sequence Following Firmware Update

```
U-Boot 1.1.1 (May 23 2007 - 21:30:12)
...
POST cpu PASSED
POST ethernet PASSED
Hit any key to stop autoboot:  0
## Booting image at fe080000 ...

IP Protocols: ICMP, UDP, TCP, IGMP

Checking all file systems...
fsck 1.37 (21-Mar-2005)
Setting kernel variables ...
```

CODE EXAMPLE A-1 Typical Boot Sequence Following Firmware Update *(Continued)*

```
... done.
Mounting local filesystems...
Cleaning /tmp /var/run /var/lock.

Identifying DOC Device Type(G3/G4/H3) ...
OK

Configuring network interfaces...Internet Systems Consortium DHCP
Client V3.0.1
Copyright 2007 Internet Systems Consortium.
All rights reserved.
For info, please visit http://www.isc.org/products/DHCP

eth0: config: auto-negotiation on, 100FDX, 100HDX, 10FDX, 10HDX.
Listening on LPF/eth0/00:14:4f:3f:8c:af
Sending on   LPF/eth0/00:14:4f:3f:8c:af
Sending on   Socket/fallback
DHCPDISCOVER on eth0 to 255.255.255.255 port 67 interval 6
eth0: link up, 100 Mbps Full Duplex, auto-negotiation complete.
DHCPDISCOVER on eth0 to 255.255.255.255 port 67 interval 15
Hostname: hostname.
Starting portmap daemon: portmap.
Initializing random number generator...done.
INIT: Entering runlevel: 3
Starting system log daemon: syslogd and klogd.
Starting periodic command scheduler: cron.
Starting IPMI Stack..... Done.
Starting OpenBSD Secure Shell server: sshd.
Starting Servicetags listener: stlistener.
Starting FRU update program: frutool.

hostname login:
```

APPENDIX **B**

Selecting a Boot Device

This appendix provides instructions on selecting a boot device.

- "Selecting a Boot Device" on page 65

Selecting a Boot Device

The boot device is specified by the setting of an OpenBoot configuration variable called `boot-device`. The default setting of this variable is `disk net`. Because of this setting, the firmware first attempts to boot from the system hard drive, and if that fails, from the on-board NET0 Gigabit Ethernet interface.

This procedure assumes that you are familiar with the OpenBoot firmware and that you know how to enter the OpenBoot environment. For more information, see the *SPARC Enterprise T5140 and T5240 Servers Administration Guide*.

Note – The serial management port on the ILOM card is preconfigured as the default system console port. For more information, see the *SPARC Enterprise T5140 and T5240 Servers Overview*.

If you want to boot from a network, you must connect the network interface to the network.

▼ To Select a Boot Device

- **At the `ok` prompt, type:**

```
ok setenv boot-device device-specifier
```

where the *device-specifier* is one of the following:

- `cdrom` – Specifies the DVD drive
- `disk` – Specifies the system boot disk (internal disk 0 by default)
- `disk0` – Specifies internal drive 0
- `disk1` – Specifies internal drive 1
- `disk2` – Specifies internal drive 2
- `disk3` – Specifies internal drive 3
- `net`, `net0`, `net1`, `net2`, `net3` – Specifies the network interfaces
- *full path name* – Specifies the device or network interface by its full path name

---

Note – The Solaris OS modifies the `boot-device` variable to its full path name, not the alias name. If you choose a nondefault `boot-device` variable, the Solaris OS specifies the full device path of the boot device.

Note – You can specify the name of the program to be booted as well as the way the boot program operates. For more information, refer to the *OpenBoot 4.x Command Reference Manual* in the *OpenBoot Collection AnswerBook* for your specific Solaris OS release.

If you want to specify a network interface other than an on-board Ethernet interface as the default boot device, you can determine the full path name of each interface by typing either of the following commands:

```
ok show-devs
ok show-nets
```

The `show-devs` command lists the system devices and displays the full path name of each PCI device.

APPENDIX **C**

Installing the Servers With the Express Rail Rackmounting Kit

This appendix provides instructions for installing the servers in an equipment rack with express (snap-in) rails. The wxpress rail rackmounting kit installs quickly, and does not require mounting screws or nuts. The kit and the installation procedures are the same for both the SPARC Enterprise T5140 and T5240 servers.

Note – If your rackmount kit came with its own instructions, use the instructions in your rackmount kit instead of the instructions in this appendix. After performing the server installation, proceed to Chapter 3 for first-time power on.

Note – The procedures in this appendix are the same for both the 1U and 2U servers. The illustrations show a 2U server only as an example.

This chapter contains the following sections:

- "Installing the Servers in a Rack With Express Rails" on page 71
- "Installing the Cable Management Arm" on page 79
- "Connecting the Server Cables" on page 79
- "Managing Cables With the CMA" on page 79
- "Dismounting the Server" on page 79

Note – References to *left* and *right* are from your viewpoint as you face either the front or the rear of the system.

Slide Rail Assembly Notes for the Express Rail Rackmounting Kit

The express rail rackmount kit has two slide rail assemblies. A slide rail assembly can be installed on either the right or left side of the rack.

Each slide rail assembly consists of a three-section slide rail and a removable mounting bracket (FIGURE C-1).

FIGURE C-1 Sections of the Express Rail Slide Rail Assembly



Figure Legend

1	Mounting bracket
2	Front section
3	Middle section
4	Rear section

- The *front*, *middle*, and *rear* sections form the *slide rail*. The middle and rear sections have holes for mounting and adjust to fit rack depths from 24 in. (61 cm) to 36.5 in. (93 cm). The front section can be extended to allow movement of the server out of the rack.

- The removable *mounting bracket* slides 14.5 in. (37 cm) out of the slide rail, then locks in place. If you unlock the mounting bracket at this point, it slides an additional 14.5 in. (37 cm) before separating from the slide rail. You can then mount the mounting bracket to the right or left side of the server chassis.
- Note that there are a total of six locks (FIGURE C-2) in a slide rail assembly. Four are on the mounting bracket. Two locks are on the slide rail. The uses of these locks are described in the following installation procedure.

FIGURE C-2 Locating the Locks on the Slide Rail Assembly for the SPARC Enterprise T5240 Server



Installing the Servers in a Rack With Express Rails

Note – Ensure that you have all of the parts in the rackmount kit before you begin the installation of the server.

The rackmount kit contains two slide rail assemblies, which can be installed on either the right or left side of the rack.

A slide rail assembly consists of two parts, a slide rail and a removable mounting bracket. The slide rail attaches to the rack posts. The mounting bracket attaches to the server chassis.

▼ To Install the Slide Rail Assemblies

1. **Pull both mounting brackets completely out of their respective slide rails.**

   a. **Simultaneously press and hold the upper and lower lock buttons of the slide rail lock (**FIGURE C-3**).**

FIGURE C-3 Unlocking the Express Rail Slide Rail Assembly



b. Pull the mounting bracket out until it stops.

c. **Slide the mounting bracket release button to the left (FIGURE C-4), then slide the mounting bracket completely out of the slide rail.**

FIGURE C-4 Express Rail Mounting Bracket Release Button



2. **Attach a mounting bracket to the right side of the server chassis.**

   a. **Position the mounting bracket against the chassis (**FIGURE C-5**). Ensure that the slide rail lock is at the front and the keyed openings on the mounting bracket are aligned with the locating pins on the side of the chassis.**

FIGURE C-5 Attaching an Express Rail Mounting Bracket to the Chassis



   b. **Ensure that the heads of the four locating pins protrude through the keyed openings in the mounting bracket. Slide the mounting bracket toward the front of the chassis until the bracket locks into place with an audible click.**

   c. **Verify that all four locating pins are trapped in the keyed openings and that the third from the front locating pin has engaged the mounting bracket lock (**FIGURE C-5**).**

3. **Attach the second mounting bracket to the left side of the server chassis.**

4. **Orient slide rails, ensuring that the ball bearing tracks (labeled FRONT) are forward (**FIGURE C-6**).**

FIGURE C-6 Express Rail Slide Rails Orientation for Installation



5. **Extend the slide rails (outer section) to fit the rack and attach the slide rails to the rack (**FIGURE C-7**).**

   You hear an audible click when the rails securely attach to the rack.

FIGURE C-7 Attaching Express Slide Rails to the Rack



Caution – Deploy the antitilt feature on the rack before continuing the installation.

▼ To Insert and Lock the Server in the Rack

1. **Deploy the antitilt feature, if the rack is so equipped.**

Caution – The weight of the servers on extended slide rails can be enough to overturn an equipment rack.

Caution – The 2U server weighs approximately 46 lb (20.7 kg). Two people are required to lift and mount the server into a rack enclosure when using the procedures in this chapter.

2. **Insert the ends of the mounting brackets into the sliding rails (**FIGURE C-8**).**
3. **Slide the server approximately halfway into the chassis (**FIGURE C-8**).**

FIGURE C-8 Inserting Express Rail Mounting Brackets Into the Slide Rails



4. **Slide the green release tab (**FIGURE C-9**).**

5. **Push the server all the way into the rack until it locks into place (**FIGURE C-9**).**

FIGURE C-9 Sliding the Express Rail Release Tab and Securing the Server in the Rack



Caution – Before continuing, verify that the server is securely mounted in the rack, and that the slide rails are locked in the mounting brackets.

Installing the Cable Management Arm

The rackmounting kit for each server comes with the same cable management arm (CMA) assembly. The CMA installation procedures are the same for both servers. See "Installing the Cable Management Arm for Both Servers" on page 24.

Connecting the Server Cables

To boot the server, you must connect and configure the network and serial ports. For instructions, see "Connecting the Server Cables for Both Servers" on page 31.

Managing Cables With the CMA

Managing the cables with the CMA is the same for both servers. See "Managing Cables With the CMA" on page 34.

Dismounting the Server

Caution – To prevent damage to your server, do not move the rack while the server is mounted.

To install or replace internal parts in the server, you must first remove the server from the rack. For the removal procedure, refer to the *SPARC Enterprise T5140 and T5240 Servers Service Manual*.

Index

Symbols

`#.` escape sequence for system console, 58

A

accessing ILOM command line, 45
adapters for serial cables, 32
address, IP, 4
addresses, web, *See* web sites
`admin` login, setting password for, 46

B

baud rate for serial terminal, 38
bits setting for serial terminal, 38
boot
  booting the Solaris OS, 55
  booting the system, 37
  OpenBoot PROM `boot` command, 56
buttons, *See* "slide rail assembly locks"

C

cable management assembly, 24 to 30
cable management bracket, description, 13
cables
  adapters for serial data cables, 32
  connecting, 31
command
  set keyswitch, 51, 53
command-line access, ILOM, 45
configuration information needed, 4
configuring the network management port, 44
connecting to the system console, 53
`console` command, 58

D

DB-9 TTY connector, 7
definitions, *See* terms, 15
deinstallation of server, 79
device identifiers, listed, 55
diagnostics, when run, 41

E

enabling the network management port, 44
escape sequence `#.` for system console, 58

F

first time AC power, 37
full disk path example, 56

G

gateway IP address, 4

H

handshaking for serial terminal, no, 39
hot-plugging USB ports, 7
http://manuals.fujitsu-siemens.com/, xv

I

ILOM
  command-line access, 45
  See also service processor
initializing the system, 53

installation instructions, optional components, reference, 3
installing
mounting brackets, 71
IP address, 4

L

LEDs, ports, and slots illustrated, 7, 8
left, 15
left and right sides defined, 15
levers, locking, *See* "slide rail assembly locks"
locating pins for mounting brackets, 71
locations of ports, slots, and LEDs (illustration), 7, 8
locks, *See* "slide rail assembly locks"
logging into service processor
using network management port, 45, 50
using serial management port, 45

M

map of OpenBoot PROM devices, 55
minimum cable connections, 6
modem not for use with the SER MGT serial management port, 32
mounting bracket
locating pins on chassis, 71
preparation for installation, 71
removing from slide rail, 71
unlocking, 71
mounting screws for rack, 19

N

netmask, 4
network management port
configuring and enabling, 44
not operational until configured, 5, 44

O

OpenBoot PROM device map, 55
optional components, 3
optional components, installation instructions in service manual, 3

P

parity for serial terminal, no, 38
`password` command, 45
path names, 55
pins, mounting bracket locating, 71
port locations illustrated, 7
ports, slots, and LEDs illustrated, 7, 8
power cycling the system, 57
powering on the system for the first time, 37
`poweroff` command, 58
`poweron` command, 51, 53

R

removing server from rack, 35, 79
reset
resetting the system with `uadmin`, 57
right and left sides defined, 15
RJ-45 cable, 6

S

screws for rack mounting, 19
serial terminal
settings, 38
server dismounting, 35
service processor
accessing with network management port, 50
accessing with serial management port, 45
connecting to the system console, 53
network management port not operational until configured, 5
powering on for the first time, 38
powering on the system, 50
See also ILOM
`set` command, 47
`set` command, 47
`show /SP/network` command, 48
`show-disks` command, 56
slide rail spacing tool, 21
slots, ports, and LEDs illustrated, 7, 8
Solaris media kit contents, 6
spacing tool for slide rails, 21
Standby mode, 34
standby voltage causes service processor to power on, 5
standby voltage, 3.3v, 41
stop bit, 38
system console escape sequence `#.`, 58

T

terms
left and right sides, 15
slide rail assembly, 10, 68
TTYA serial port, 7

U

`uadmin` command, 57
unlocking mounting bracket, 71

W

web site
http://manuals.fujitsu-siemens.com/, xv

Herausgegeben von / Published by
Fujitsu Siemens Computers GmbH

Bestell-Nr./ Order No.:
U41767-J-Z816-1-76

U41767-J-Z816-1-76